

PRE-CONSTRUCTION SUBTERRANEAN TERMITE TREATMENT - HORIZONTAL BARRIER

General Information

For use as an insecticide on ornamentals grown in interiorscapes, for perimeter insect control on lawns, ornamental trees and shrubs around residential, institutional, public, commercial and industrial buildings, parks, recreational areas and athletic fields, treatment of preconstruction lumber and logs, and for use on buildings/structures. For control of subterranean termites: For use by individuals/firms licensed or registered by the state to apply termiticide products. States may have more restrictive requirements regarding qualifications of persons using this product. Consult the pest control regulatory agency of your state prior to use of this product.

GENERAL USE INFORMATION

Important

Tengard SFR is toxic to fish. Exercise care when making applications near ponds, lakes, streams, reservoirs and other aquatic environments where fish are present.

Tengard SFR may also be used as a broadcast or spot application in crawl spaces and indoors to carpeting, wood, tile, concrete or other structural building materials as a crack and crevice injection, or paint-on treatment. Consult tables for specific use instructions.

Tengard SFR can be applied to interior plantscapes, and landscape ornamental gardens including parks, lawns and grounds.

For advice concerning current control practices with relation to specific local conditions, consult your local State Cooperative Extension or regulatory agencies.

Tengard SFR is formulated as an emulsifiable concentrate (EC) formulation and is to be diluted with water and applied as an emulsion. When tank mixing as an emulsion with other products, observe all precautions and limitations on the labels of each product in the mixture.

Tengard SFR can be tank-mixed with pyrethrin-containing products or Insect Growth Regulators (IGRs). Do not tank mix with dichlorvos (DDVP) or other fumigant products. Do not tank mix when applied as a soil termiticide.

Applications for the Control of Subterranean Termites

General Application Instructions

Tengard SFR acts as an insecticidal barrier to control and prevent subterranean termite (*Coptotermes*, *Heterotermes*, *Reticulitermes* and *Zootermopsis*) infestations in and around structures. For effective control the insecticide emulsion must be adequately dispersed in the soil to establish a barrier between the structure and the termites in the soil. To establish an effective insecticidal barrier with this product the proper control practices and application techniques should be selected by a trained service technician familiar with current termite control practices.

When treating adjacent to an existing structure, the applicator must check the area to be treated, and immediately adjacent areas of the structure, for visible and accessible cracks and holes to prevent any leaks or significant exposures to persons occupying the structure. People present or residing in the structure during application must be advised to remove their pets and themselves from the structure if they see any signs of leakage. After application, the applicator is required to check for leaks. All leaks resulting in the deposition of termiticide in locations other than those prescribed on the label must be cleaned up prior to leaving the application site. Do not allow people or pets to contact contaminated areas or to reoccupy contaminated areas of the structure until the clean up is completed.

When applying Tengard SFR indoors, procedures should include structural design consideration and variable post-application effects from heating, ventilation and air conditioning systems (HVAC). Outdoor application procedures should include consideration of such variable factors effected by soil type, soil compaction, grade conditions, utilities and, location and type of domestic water supply. Contamination of public and private water supplies must be avoided by using anti-backflow equipment or procedures to prevent siphonage of insecticide into water supplies. Do not contaminate wells or cisterns.

Limitations, Restrictions, and Exceptions

PRE-CONSTRUCTION SUBTERRANEAN TERMITE TREATMENT - HORIZONTAL BARRIER

Application Volume Considerations: Adjustments to application volumes are often needed to ensure thorough and complete coverage in different soil types while keeping the application rate as close as possible to the specified labeled use rate. Certain types of soils, such as clay, require lower volumes of water due to their low permeability characteristics. In such cases reduced volumes of emulsion can be used while still delivering the necessary concentration of termiticide to the soil (Rate/Volume Conversion Chart in the label).

Application Volume Adjustments: Where necessary to reduce the application volume for pre- and postconstruction treatments, the volume of a 1.0% emulsion may be reduced by 1/2 the labeled volume or a 2.0% emulsion may be applied at 1/4 the labeled volume (see Volume Adjustments for Horizontal and Vertical Applications in the label).

Pre-Construction Treatment

Tengard SFR may be applied as a vertical and/or horizontal insecticidal barrier to control or prevent infestation of subterranean termites using a 0.5% emulsion.

Prior to each application, applicators must notify the general contractor, construction superintendent, or similar responsible party, of the intended termiticide application and intended sites of application and instruct the responsible person to notify construction workers and other individuals to leave the area to be treated during application and until the termiticide is absorbed into the soil.

DO NOT APPLY AT A LOWER DOSAGE AND/OR CONCENTRATION THAN SPECIFIED ON THE LABEL FOR APPLICATIONS PRIOR TO THE INSTALLATION OF THE FINISHED GRADE.

When treating foundations deeper than 4 feet, apply the termiticide as the backfill is being replaced, or if the construction contractor fails to notify the applicator to permit this, treat the foundation to a minimum depth of 4 feet after the backfill has been installed. The applicator must trench and rod into the trench or trench along the foundation walls and around pillars and other foundation elements, at the rate prescribed from grade to a minimum depth of 4 feet. When the top of the footing is exposed, the applicator must treat the soil adjacent to the footing to a depth not to

exceed the bottom of the footing. However, in no case should a structure be treated below the footing.

Horizontal Barrier:

Pre-construction horizontal termiticide barrier applications are most commonly made to soil that will be covered (i.e., concrete slabs and footings, porches, stairs and crawl spaces). Using a coarse spray nozzle at low pressure (less than 50 psi) apply 1 gallon of a 0.5% emulsion per 10 square feet. If fill consists of gravel or other coarse material use a rate of 1.5 gallons of a 0.5% emulsion per 10 square feet (see Volume Adjustment Chart in the label). If more than 24 hours is expected between the time of application and pouring of the concrete, it is recommended that the site be covered with a water proof barrier (polyethylene).

Method

[Spray](#)

Timings

[N. A.](#)