

FOAM APPLICATIONS - APPLICATION UNDER SLABS OR TO SOIL IN CRAWL SPACES TO PREVENT OR CONTROL TERMITES [HORIZONTAL BARRIER]

General Information

For use as an insecticide on ornamentals grown in interiorscapes, for perimeter insect control on lawns, ornamental trees and shrubs around residential, institutional, public, commercial and industrial buildings, parks, recreational areas and athletic fields, treatment of preconstruction lumber and logs, and for use on buildings/structures. For control of subterranean termites: For use by individuals/firms licensed or registered by the state to apply termiticide products. States may have more restrictive requirements regarding qualifications of persons using this product. Consult the pest control regulatory agency of your state prior to use of this product.

GENERAL USE INFORMATION

Important

Tengard SFR is toxic to fish. Exercise care when making applications near ponds, lakes, streams, reservoirs and other aquatic environments where fish are present.

Tengard SFR may also be used as a broadcast or spot application in crawl spaces and indoors to carpeting, wood, tile, concrete or other structural building materials as a crack and crevice injection, or paint-on treatment. Consult tables for specific use instructions.

Tengard SFR can be applied to interior plantscapes, and landscape ornamental gardens including parks, lawns and grounds.

For advice concerning current control practices with relation to specific local conditions, consult your local State Cooperative Extension or regulatory agencies.

Tengard SFR is formulated as an emulsifiable concentrate (EC) formulation and is to be diluted with water and applied as an emulsion. When tank mixing as an emulsion with other products, observe all precautions and limitations on the labels of each product in the mixture.

Tengard SFR can be tank-mixed with pyrethrin-containing products or Insect Growth Regulators (IGRs). Do not tank mix with dichlorvos (DDVP) or other fumigant products. Do not tank mix when applied as a soil termiticide.

Applications for the Control of Subterranean Termites

General Application Instructions

Tengard SFR acts as an insecticidal barrier to control and prevent subterranean termite (*Coptotermes*, *Heterotermes*, *Reticulitermes* and *Zootermopsis*) infestations in and around structures. For effective control the insecticide emulsion must be adequately dispersed in the soil to establish a barrier between the structure and the termites in the soil. To establish an effective insecticidal barrier with this product the proper control practices and application techniques should be selected by a trained service technician familiar with current termite control practices.

When treating adjacent to an existing structure, the applicator must check the area to be treated, and immediately adjacent areas of the structure, for visible and accessible cracks and holes to prevent any leaks or significant exposures to persons occupying the structure. People present or residing in the structure during application must be advised to remove their pets and themselves from the structure if they see any signs of leakage. After application, the applicator is required to check for leaks. All leaks resulting in the deposition of termiticide in locations other than those prescribed on the label must be cleaned up prior to leaving the application site. Do not allow people or pets to contact contaminated areas or to reoccupy contaminated areas of the structure until the clean up is completed.

When applying Tengard SFR indoors, procedures should include structural design consideration and variable post-application effects from heating, ventilation and air conditioning systems (HVAC). Outdoor application procedures should include consideration of such variable factors effected by soil type, soil compaction, grade conditions, utilities and, location and type of domestic water supply. Contamination of public and private water supplies must be avoided by using anti-backflow equipment or procedures to prevent siphonage of insecticide into water supplies.

Do not contaminate wells or cisterns.

Limitations, Restrictions, and Exceptions

FOAM APPLICATIONS - APPLICATION UNDER SLABS OR TO SOIL IN CRAWL SPACES TO PREVENT OR CONTROL TERMITES [HORIZONTAL BARRIER]

Foam Applications

Tengard SFR emulsion may be converted to a foam, and the foam used to control and prevent termite infestation. When applying the product as either a foam application alone, or in combination with an emulsion treatment, do not exceed the maximum-labeled application rate. Exercise care and safety around electrical utilities. Note location of electrical sources prior to foaming voids to avoid possible shock hazard. Localized Application Foam may be used to treat voids to control or prevent localized infestations of: termites, ants, bees, wasps or other arthropods harboring in voids. Application may be made to voids such as: behind veneers, piers (concrete or wood), chimneys, into rubble and stone foundations, into block voids, structural voids (i.e., between stud walls), poles, stumps, and wood in crawlspaces using either the foam alone or in combination with liquid emulsion.

Note location of electrical sources prior to foaming voids to avoid possible shock hazards.

Application Under Slabs or to Soil in Crawlspaces to Prevent or Control Termites

Application may be made using Tengard SFR foam alone or in combination with liquid emulsion. The equivalent of at least 1 gallon (1.6 ounces of Tengard SFR concentrate) of 0.5% emulsion per 10 square feet (horizontal barrier) must be applied either as emulsion, foam, or a combination of both. For a foam only application, apply Tengard SFR concentrate in sufficient foam concentration and foam volume to deposit 6.4 ounces of concentrate per 10 linear feet or 1.6 ounces of concentrate per 10 square feet. For example, 1 gallon of 2% emulsion generated as foam to cover 10 linear feet is equal to the application of 4 gallons of 0.5% emulsion per 10 linear feet.

Foam and liquid application must be consistent with volume and active ingredient instructions in order to ensure proper application has been made. The volume and amount of active ingredient are essential to an effective treatment. At least 75% of

the labeled liquid emulsion volume of product must be applied, with the remaining percent delivered to appropriate areas using foam application. Refer to label and use recommendations of the foam manufacturer and the foaming equipment manufacturer.

Foam applications are generally a good supplement to liquid treatments in difficult areas, but may be used alone in difficult spots.

Method

[Foam](#)

Timings

[N. A.](#)