

OTHER CONSTRUCTION MATERIALS: CONCRETE, OR CINDER BLOCK CLEANUP METHODS

General Information

DIRECTIONS FOR USE

SaniDate 5.0 Sanitizer/Disinfectant works best when diluted with water containing minimal levels of organic or inorganic materials, and with water having a neutral pH. Thoroughly rinse out tank with water before mixing concentrate. This product will readily mix with clean, neutral water and does not require agitation.

SaniDate 5.0 Sanitizer/Disinfectant concentrate should not be combined or mixed with any other pesticide concentrates.

This product is not for use on medical device surfaces.

Before use in federally inspected meat and poultry food processing plants and dairies, food products and packaging materials must be removed from room or carefully protected. A potable water rinse is not allowed (Do not rinse) following use of the product as a sanitizer on previously cleaned hard surfaces provided that the surfaces are adequately drained before contact with food so that little or no residue remains.

Limitations, Restrictions, and Exceptions

Other Construction Materials: Concrete, or Cinder Block

Cleanup Methods

- Gloves, disposable full body clothing, headgear, foot coverings, full-face respirator with HEPA filter are the recommended personal protective equipment.
- Select method most appropriate to situation. Since molds gradually destroy the things they grow on, if mold growth is not addressed promptly, some items may be damaged such that cleaning will not restore their original appearance. If mold growth is heavy and items are valuable or important, you may wish to consult a restoration/water damage/remediation expert. Please note that these are

guidelines; other cleaning methods may be preferred by some professionals.

- Use professional judgment to determine prudent levels of Personal Protective Equipment and containment for each situation, particularly as the remediation site size increases and the potential for exposure and health effects rises. Assess the need for increased Personal Protective Equipment if, during the remediation, more extensive contamination is encountered than was expected. These guidelines are for damage caused by clean water. If you know or suspect that the water source is contaminated with sewage, or chemical or biological pollutants, then the Occupational Safety and Health Administration (OSHA) requires PPE and containment. An experienced professional should be consulted if you and/or your remediators do not have expertise in remediating contaminated water situations.

Method 1: Wet vacuum (in the case of porous materials, some mold spores/fragments will remain in the material but will not grow if the material is completely dried.

Method 2: High-efficiency particulate (HEPA) vacuum after the material has been thoroughly dried. Dispose of the contents of the HEPA vacuum in well-sealed plastic bags.

Method

[Surface](#)

[Spray](#)

Timings

[N.A.](#)