

PRE-CONSTRUCTION TREATMENT: HOLLOW BLOCK FOUNDATIONS OR VOIDS

General Information

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

Limitations, Restrictions, and Exceptions

PRE-CONSTRUCTION TREATMENT

Do not apply at a lower dosage and/or concentration than that specified on the label when applying before installation of the finished grade.

Prior to each application, applicators must notify the general contractor, construction superintendent, or similar responsible party, of the intended termiticide application and intended sites of application and instruct the responsible person to notify construction workers and other individuals to leave the area to be treated during application and until the termiticide is absorbed into the soil.

HOLLOW BLOCK FOUNDATIONS OR VOIDS: Hollow block foundations or voids in masonry resting on the footing may be treated to provide a continuous chemical treated zone in the voids at the footing. Apply 2 gallons of solution per 10 linear feet to the lower part of the void so that it reaches the top of the footing or soil.

Examine treatment of voids in block or rubble foundation walls closely. Applicators must inspect areas of possible runoff as a precaution against application leakage in

the treated areas. Some areas may not be treatable or may require mechanical alteration prior to treatment.

All leaks resulting in the deposition of termiticide in locations other than those prescribed on the label must be cleaned up prior to leaving the application site (refer to Precautionary Statements). Do not allow people or pets to contact or to reoccupy the contaminated areas of the structure until the clean up is completed.

Method

[Spray](#)

Timings

[N.A.](#)