

## **POST-CONSTRUCTION TREATMENT: CRAWL SPACES**

### General Information

#### DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

#### Limitations, Restrictions, and Exceptions

#### POST-CONSTRUCTION TREATMENT

**CRAWL SPACES:** When there is not enough clearance between floor joists and ground surfaces to allow applicator access, excavate the area, if possible, and treat according to crawl spaces (refer to Pre-Construction Treatment). If excavation is not possible, treat crawl space soil and wood to prevent surface access by termites. Apply 1 gallon of solution (see APPLICATION VOLUME) per 10 square feet to create a uniform chemical treated zone. Use a very coarse spray at a pressure not greater than 25 psi at the treatment tool when the valve is open. If a crawl space cannot be reached with the application wand, use extension wands or other suitable equipment to apply a coarse spray on the soil, wood and structural members which contact the soil, at the rates above. Do not apply to inaccessible crawl space areas using pressures greater than 25 psi at the treatment tool when the valve is open. Treatment may also be made by drilling through the foundation wall or through the floor above and treating the soil perimeter using a rate of 1 gallon of solution per 10 square feet. Drill spacing must be at intervals not to exceed 16 inches. Many states have smaller intervals so check state regulations which may apply.

#### Method

Spray

Timings

N.A.