

POST-CONSTRUCTION TREATMENT: SHALLOW FOUNDATIONS

General Information

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

Limitations, Restrictions, and Exceptions

POST-CONSTRUCTION TREATMENT

SHALLOW FOUNDATIONS: For shallow foundations, one foot or less in depth, dig a narrow trench about 6 inches wide and deep along both the outside and inside of the foundation walls, being careful not to dig below the bottom of the footings. If the foundation has an exposed footing, dig a trench alongside the footing taking care not to undermine the footing. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet to the top of footer to create a uniform treated zone. Apply the dilution to the trench and mix it with the soil as it is placed in the trench.

Method

[Spray](#)

Timings

[N.A.](#)