

## **POST-CONSTRUCTION TREATMENT: BASEMENTS - OUTSIDE PERIMETER**

General Information

### **DIRECTIONS FOR USE**

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

Limitations, Restrictions, and Exceptions

### **POST-CONSTRUCTION TREATMENT**

**BASEMENTS - OUTSIDE PERIMETER:** Along the outside of the exterior walls, apply by trenching or rodding within the trench. Rodding depth must be to the top of the footer, or to a minimum of 4 feet or according to state or local regulations. When rodding through a trench, dig a narrow trench about 6 inches wide and 6 inches deep, then apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth to create a uniform treated zone by rodding through the trench. Use a low pressure spray to treat soil which will be placed into the trench after rodding. Mix spray solution with the soil as it is being placed in the trench.

Method

[Spray](#)

Timings

[N.A.](#)