

STRUCTURES WITH ADJACENT WELLS / CISTERNS AND/OR OTHER WATER BODIES

General Information

APPLICATION VOLUME

It is recommended that application volumes described in the PREMISE 75 Insecticide \("DIRECTIONS FOR USE\) be used whenever possible. However, where soil conditions will not accept application of 4 gallons of PREMISE 75 Insecticide per 10 linear feet, twice the PREMISE concentration may be applied in 2 gallons of solution per 10 linear feet. For example, if 0.05% is the correct use rate to be applied in 4 gallons of water, then 2 gallons of 0.1% dilution may be used per 10 linear feet to deliver an equivalent amount of PREMISE per unit of soil.

CONTROL - GENERAL

Treatment standards for subterranean termite control may vary due to regulations, treatment procedures, soil types, construction practices and other factors. The purpose of chemical soil treatment for termite control is to establish a continuous chemical treated zone (horizontal and/or vertical as needed) between the wood and other cellulose material in the structure and the termite colonies in the soil. Follow all federal, state, and local regulations and treatment standards for protection of a structure from termites. In some instances where an aerial or above ground colony is established, supplemental treatments to control the termites, landscape modifications, and/or structural repairs may be needed to deprive termites of a moisture source. Use a 0.05% to 0.1% dilution based on local recommendations. Generally a 0.05% dilution is used for typical control situations. Where severe or persistent infestations occur, a 0.1% dilution may be used.

RETREATMENT

Retreatment for subterranean termites can only be performed if there is clear evidence of reinfestation or disruption of the treated zone due to construction, excavation, or landscaping and/or evidence of the breakdown of the termiticide treated zone in the soil. These vulnerable or reinfested areas may be retreated in accordance with application techniques described in this product's labeling. The

timing and type of these retreatments will vary, depending on factors such as termite pressure, soil types, soil conditions and other factors which may reduce the effectiveness of the treated zone. Retreatment may be made as either a spot or complete treatment.

When a structure is not known to be reinfested and the treated zone is not disturbed, but where the structure was last treated five or more years ago, retreatment may be performed if, in the judgement of the applicator, it is necessary to ensure adequate protection of the structure. In determining the timing of any retreatment, the applicator should consider efficacy and/or degradation data and/or sitespecific conditions and previous experience that indicate a vulnerability of the structure to termite attack.

Annual retreatment of the structure is prohibited unless there is clear evidence that reinfestation or treated zone disruption has occurred.

GENERAL PRECAUTIONS FOR APPLICATIONS

After treatment, plug and fill all holes drilled in concrete slab areas of the building with a suitable sealant. Do not apply solution until location of heat pipes, ducts, water and sewer lines and electrical conduits are known and identified. Caution must be taken to avoid puncturing and injection into these structural elements.

Do not plant for the purpose of consumption, edible plants into the treated areas of soil.

Avoid contamination of public and private water supplies.

Use anti-backflow equipment or an air gap on filling hoses.

Consult State, Federal, or local authorities for information regarding the approved treatment practices for areas in close proximity to potable water supplies.

Limitations, Restrictions, and Exceptions

TREATMENT AROUND WELLS OR CISTERNS: Do not contaminate wells or cisterns.

Structures With Adjacent Wells / Cisterns and/or Other Water Bodies:

Applicators must inspect all structures with nearby water sources such as wells, cisterns, surface ponds, streams, and other bodies of water and evaluate, at a

minimum, the treatment recommendations listed below prior to making an application.

1. Prior to treatment, if feasible, expose the water pipe(s) coming from the well to the structure, if the pipe(s) enter the structure within 3 feet of grade.
2. Prior to treatment applicators are advised to take precautions to limit the risk of applying the termiticide into subsurface drains that could empty into any bodies of water. These precautions include evaluating whether application of the termiticide to the top of the footer may result in contamination of the subsurface drain. Factors such as depth to the drain system and soil type and degree of compaction should be taken into account in determining the depth of treatment.
3. When appropriate (i.e., on the water side of the structure), the treated backfill technique (described above) can also be used to minimize off-site movement of termiticide.

Method

[N.A.](#)

Timings

[N.A.](#)