

# **SUBTERRANEAN TERMITE CONTROL - STRUCTURES WITH WELLS/CISTERNS INSIDE FOUNDATIONS**

## General Information

### General Information on the Use of This Product

Not for use on plants being grown for sale or other commercial use, or for commercial seed production, or for research purposes. For use on plants intended for aesthetic purposes or climatic modification and being grown in interior plantscapes, ornamental gardens or parks, or lawns and grounds.

Choice of appropriate procedures should include consideration of such variable factors as the design of the structure, location of heating, ventilation, and air conditioning (HVAC) systems, water table, soil type, soil compaction, grade conditions, and location and type of domestic water supplies and utilities.

For advice concerning current control practices with relation to the specific local conditions, consult resources in structural pest control and state cooperative extension and regulatory agencies.

## Attention

Do not apply to pets, crops, or sources of electricity.

Do not allow people or pets on treated surfaces, such as carpets until the spray has dried.

Do not use concentrate or emulsion in fogging equipment.

Firewood is not to be treated.

During any application to overhead areas of structure, cover surfaces below with plastic sheeting or similar material (except where exempt).

Do not allow spray to contact food, foodstuffs, food contacting surfaces, food utensils or water supplies.

Thoroughly wash dishes and food handling utensils with soap and water if they

become contaminated by application of this product.

Do not treat areas where food is exposed.

During indoor surface applications do not allow dripping or run-off to occur.

Do not apply this product in patient rooms or in any rooms while occupied by the elderly or infirm.

Do not apply when occupants are present in the immediate area in institutions such as libraries, sport facilities, etc.

Do not apply to classrooms when in use.

Do not touch treated surface until dry.

Not for use in voids insulated with rigid foam.

Refer in the supplemental label for Clarification of Directions for Use for Pre and Post Construction Termite Treatment for distribution and use only within Mississippi.

Limitations, Restrictions, and Exceptions

#### SUBTERRANEAN TERMITE CONTROL

The use of this product prevents and controls termite infestations in and around structures and constructions.

The dilute insecticidal emulsion must be adequately dispersed in the soil to establish a barrier between the wood and the termites in the soil. As a good practice: 1) all non-essential wood and cellulose containing materials should be removed from around foundation walls, crawl spaces and porches; 2) eliminate termite access to moisture by repairing faulty plumbing and/or construction grade. Soil around untreated structural wood in contact with soil should be treated as described below.

To establish an effective insecticidal barrier with this product the service technician must be familiar with current termite control practices such as: trenching, rodding, sub-slab injection, coarse fan spraying of soil surfaces, crack and crevice (void) injection, excavated soil treatment, and brush or spray applications to infested or susceptible wood. These techniques must be correctly employed to prevent or

control infestations by subterranean termites such as: *Coptotermes*, *Heterotermes*, *Reticulitermes* and *Zootermopsis*. The biology and behavior of the species involved should be considered by the service technician in determining which control practices to use to eliminate or prevent the termite infestation.

Important: Contamination of public and private water supplies must be avoided by following these precautions: Use anti-backflow equipment or procedures to prevent siphonage of insecticide into water supplies. Do not contaminate cisterns or wells. Do not treat soil that is water saturated or frozen or in any conditions where runoff or movement from the treatment area (site) is likely to occur.

Permethrin the active ingredient in Dragnet SFR termiticide/insecticide, is extremely toxic to fish and aquatic invertebrates. Care should be used when making applications near bodies of water. As part of FMC's stewardship program, refer to available support literature on well water, ponds and stream concerns. Locate sources of water discharge from structures, such as french drains and sump systems. Turn off discharge pumps until after application is complete. Observe for any change in color or odor of effluent discharge. Consult state and local specifications for recommended distances of wells from treated areas, or if such regulations do not exist, refer to Federal Housing Administration Specifications (H.U.D.) for guidance.

Note: Crawlspace are to be considered inside of the structure.

Critical Areas: Critical areas include areas where the foundation is penetrated by utility services, cracks and expansion joints, bath traps and areas where cement constructions have been poured adjacent to the foundation such as stairs, patios, and slab additions.

#### Structures with Wells/Cisterns Inside Foundations

Structures that contain wells or cisterns within the foundation of a structure can only be treated using the following techniques:

1. Do not treat soil while it is beneath or within the foundation or along the exterior perimeter of a structure that contains a well or cistern. The treated backfill method must be used if soil is removed and treated outside/away from the foundation. The treated backfill technique is described as follows:

- a. Trench and remove soil to be treated onto heavy plastic sheeting or similar material or into a wheelbarrow.
  - b. Treat the soil at the rate of 4 gallons of dilute emulsion per 10 linear feet per foot of depth of the trench, or 1 gallon per 1.0 cubic feet of soil. See “Mixing Directions section of the label. Mix thoroughly into the soil taking care to contain the liquid and prevent runoff or spillage.
  - c. After the treated soil has absorbed the diluted emulsion, replace the soil into the trench.
2. Treat infested and/or damaged wood in place using an injection technique such as described in the “Control of Wood Infesting Insects” section of the label

Method

[Soil application](#)

Rates

[field\\_rates 0](#)

•

Timings

[N.A.](#)