

TREATMENT AROUND WELLS OR CISTERNS

General Information

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

Limitations, Restrictions, and Exceptions

Structures with Wells/Cisterns Inside Foundations: Structures that contain wells or cisterns within the foundation of a structure may only be treated using the techniques below.

1. Do not apply within 5 feet of any well or cistern by rodding and/or trenching or by the backfill method. Treat soil between 5 and 10 feet from the well or cistern by the backfill method only. Treatment of soil adjacent to water pipes within 3 feet of grade must only be done by the backfill method.

a) Trench and remove soil to be treated onto heavy plastic sheeting or similar material or into a wheelbarrow.

b) Treat the soil at the rate of 4 gallons of solution per 10 linear feet per foot of the trench, or 1 gallon per 1.0 cubic feet of soil. Mix thoroughly into the soil taking care to contain the liquid and prevent runoff or spillage.

c) After the treated soil has absorbed the solution, replace the soil into the trench.

2. Treat infested and/or damaged wood in place using an injection technique such

as described in the \"Control of Wood Infesting Pests\" section of the label.

Structures with Adjacent Wells/Cisterns and/or Other Water Bodies: Applicators must inspect all structures with nearby water sources such as wells, cisterns, surface ponds, streams, and other bodies of water and evaluate, at a minimum, the treatment specifications listed below before making an application.

1. Before treatment, if feasible, expose the water pipe(s) coming from the well to the structure, if the pipe(s) enter the structure within 3 feet of grade.
2. Before treatment applicators are advised to take precautions to limit the risk of applying the termiticide into subsurface drains that could empty into any bodies of water. These precautions include evaluating whether application of the termiticide to the top of the footer may result in contamination of the subsurface drain. Consideration must be given to factors such as depth to the drain system and soil type and degree of compaction when determining the depth of treatment.
3. When appropriate (i.e., on the water side of the structure), the treated backfill technique (described above) can also be used to minimize off-site movement of termiticide.

Method

[Soil Treatment](#)

Timings

[N. A.](#)