

DISINFECTION OF NON-FOOD CONTACT PACKAGING EQUIPMENT

General Information

DIRECTIONS FOR USE

SaniDate 5.0 Sanitizer/Disinfectant works best when diluted with water containing minimal levels of organic or inorganic materials, and with water having a neutral pH. Thoroughly rinse out tank with water before mixing concentrate. This product will readily mix with clean, neutral water and does not require agitation.

SaniDate 5.0 Sanitizer/Disinfectant concentrate should not be combined or mixed with any other pesticide concentrates.

This product is not for use on medical device surfaces.

Before use in federally inspected meat and poultry food processing plants and dairies, food products and packaging materials must be removed from room or carefully protected. A potable water rinse is not allowed (Do not rinse) following use of the product as a sanitizer on previously cleaned hard surfaces provided that the surfaces are adequately drained before contact with food so that little or no residue remains.

Limitations, Restrictions, and Exceptions

DISINFECTION OF NON-FOOD CONTACT PACKAGING EQUIPMENT

1. Prior to use of this product, remove gross soil particles from surfaces to be treated. For heavily soiled surfaces, a pre-wash is required.
2. For disinfection against beverage spoilage organisms that include *Pediococcus damnosus*, *Lactobacillus malefermentans*, and *Saccharomyces cerevisiae* apply 0.5 fl. oz. of SaniDate 5.0 Sanitizer/Disinfectant per gallon of water to surfaces at a temperature of 25° to 45° C.
3. Allow to remain wet with solution for ten (10) minutes.
4. Rinse surfaces thoroughly with potable water before operations are resumed.

Method

[Spray](#)

Rates

[field_rates 0](#)

•

Timings

[N.A.](#)