

DISINFECTION OF WATER FILTER MEDIA, MEMBRANES AND RELATED COMPONENTS AND SYSTEMS - FOR CURATIVE TREATMENT

General Information

StorOx 2.0 works best when diluted with water with minimal levels of organic or inorganic materials, and with water having a neutral pH. Thoroughly rinse out tank with water before mixing concentrate. StorOx 2.0 will readily mix with clean, neutral water and does not require agitation.

StorOx 2.0 concentrate should not be combined or mixed with any other pesticide concentrates.

Limitations, Restrictions, and Exceptions

DISINFECTION OF WATER FILTER MEDIA, MEMBRANES AND RELATED COMPONENTS AND SYSTEMS (Not Approved For Use in California)

StorOx 2.0 is an effective disinfectant used for the reduction and removal of bio-organisms on the surfaces of the filter and membrane media, media housings, and related devices and equipment. StorOx 2.0 may be used for filter media or related system components or in Clean in Place (CIP) systems. Disinfection and/or treatment of filter media and membrane in potable water systems should be performed when system is NOT in use or online.

StorOx 2.0 has been tested for compatibility with a wide range of materials of construction. StorOx 2.0 is suitable for use with most nonmetallic and metallic piping, valves, pumps and tanks. Long term exposure to concentrate may accelerate corrosion of galvanized steel, bronze, brass or copper. Dirty or moderate to heavy soiled filters and or membranes should be cleaned in accordance with the manufacturer's guidelines to remove contaminants from the membrane surface.

StorOx 2.0 contains a minimum amount of surfactant; additional surfactant can be added to the treatment solution. Contact the BioSafe Systems and/or authorized distributor for clarification or additional surfactant compatibility information.

For Curative Treatments:

For filters and or filtration media, use a rate of 0.25 to 2.5 fl. oz. per gallon (or a rate range of 1:50-1:500). Immerse the filter and allow to soak for a minimum of ten (10) minutes. Drain filter media and then rinse with clean water. Prior to placing filter back on line, test a sample of the filtrate using BioSafe Test Strips to determine remaining active ingredient levels.

Method

[Soak](#)

Timings

[N.A.](#)