

## **FOR CLEAN IN PLACE CIP APPLICATION**

### General Information

#### DIRECTIONS FOR USE

SaniDate 5.0 Sanitizer/Disinfectant works best when diluted with water containing minimal levels of organic or inorganic materials, and with water having a neutral pH. Thoroughly rinse out tank with water before mixing concentrate. This product will readily mix with clean, neutral water and does not require agitation.

SaniDate 5.0 Sanitizer/Disinfectant concentrate should not be combined or mixed with any other pesticide concentrates.

This product is not for use on medical device surfaces.

Before use in federally inspected meat and poultry food processing plants and dairies, food products and packaging materials must be removed from room or carefully protected. A potable water rinse is not allowed (Do not rinse) following use of the product as a sanitizer on previously cleaned hard surfaces provided that the surfaces are adequately drained before contact with food so that little or no residue remains.

#### Limitations, Restrictions, and Exceptions

#### DISINFECTION OF WATER FILTER MEDIA, MEMBRANES AND RELATED COMPONENTS AND SYSTEMS

SaniDate 5.0 Sanitizer/Disinfectant is an effective disinfectant used for the reduction and removal of bio-organisms on the surfaces of the filter and membrane media, media housings, and related devices and equipment. It may be used for filter media or related system components or in Clean in Place (CIP) systems.

Disinfection and/or treatment of filter media and membrane in potable water systems should be performed when system is NOT in use or online.

For clean in place (CIP) applications involving filters, use a rate of 2.5 to 10.25 fl. oz. per 100 gallons. Re-circulate solution for a minimum of 10 minutes. Upon completion of cleaning cycle, flush filter housings and/or assemblies with clean

water. Test a sample of water being used to flush filter media with BioSafe Systems Test Strips to determine levels of active ingredients remaining in the flush water.

Method

[Spray](#)

Rates

[field rates 0](#)

- 

Timings

[N.A.](#)