

POST-CONSTRUCTION TREATMENT: CONCRETE SLAB-ON-GROUND OR BASEMENTS

General Information

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

Limitations, Restrictions, and Exceptions

POST-CONSTRUCTION TREATMENT

CONCRETE-SLAB-ON-GROUND: To apply under the slab in areas such as attached porches, carports, entrance platforms, garages and similar slab structures, it may be necessary to drill through the slab or exterior foundation. Space drill holes should be spaced so that a continuous chemical treated zone is created. Treat all existing cracks and cold, construction, or expansion joints. Also, treat around bath traps, plumbing and utility services which penetrate the slab. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet per foot of depth to provide a uniform treated zone. DO NOT TREAT UNTIL LOCATION OF HEAT OR AIR CONDITIONING DUCTS AND VENTS IS KNOWN AND EACH IS LOCATED. USE EXTREME CAUTION TO AVOID CONTAMINATION OF DUCTS AND VENTS. Plug and fill all drilled holes in commonly occupied areas with a suitable sealant. If plugs are not constructed of non-cellulose material, they must be covered by an impervious, non-cellulose material. An application must be made by trenching or trenching and rodding around the outside of the foundation wall. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet per foot of depth to create a uniform

treated zone. When trenching, make the trench along the outside foundation about 6 inches wide and 6 inches deep. Use a low pressure spray to treat soil as it is being placed in the trench.

Rodding can be done from the bottom of a shallow trench. When rodding, space rod holes to create a continuous chemical treated zone, not greater than 12 inches, to be deposited along the treated area. Rod hole depth must not extend below the footing.

Method

[Spray](#)

Timings

[Post-construction treatment](#)