

CONTROL OF WOOD INFESTING PESTS: DRYWOOD TERMITES AND WOOD-INFESTING BEETLES OR BORERS

General Information

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

NOTE: Not For Use in New York State or California

Do not apply this product in a way that will contact workers or other persons, either directly or through drift. Only protected handlers may be in the area during application. For any requirements specific to your State or Tribe, consult the Agency responsible for pesticide regulation.

Apply only when wind speed is 10 mph or less at the application site.

Limitations, Restrictions, and Exceptions

Drywood termites and wood-infesting beetles or borers (including powder post beetles, anobiid or deathwatch beetles, false powder post beetles, old house borers, wharf borers, or ambrosia oak bark beetles). Galleries and structure voids can be treated with sprays, mists, or foams of a 0.05% to 0.1 % Sharda Imidacloprid 70 WDG solution. Locate galleries by using visual signs (frass or pellets, blistered wood, emergence or clean cut holes), the presence of live insects, mechanical sounding techniques, or listening devices (e.g., stethoscopes, acoustic emission detectors). Drill holes to receive the injector tip or treatment tool. Distribute drill holes to adequately cover the gallery system. (NOTE: Do not drill where electrical wiring, plumbing lines, etc. are located). Apply Sharda Imidacloprid 70 WDG solutions using low pressure (about 20 psi) spray or by misting, or where appropriate, by foaming. It is not necessary to treat to the point where runoff is detected from adjacent holes. (NOTE: Do not apply where electrical shock hazards exist). Seal drill holes after treatment. Also, wood surfaces can be sprayed or misted with a 0.05% to 0.1% solution, or where appropriate, use a sufficient volume of foam. For inaccessible surfaces, drill and treat the interior of structural voids. Surfaces treated may include exposed wooden surfaces in crawl spaces, basements, or attics, wooden exterior

surfaces such as decks, fencing, or siding, structural voids, channels in damaged wood, in spaces between members of a structure, and in junctions between wood and foundations. Apply by brushing or as a coarse, low pressure (about 20 psi) spray to the wood surface; apply sufficient volume to cover the surface to the point of wetness, but avoid applying to the point of runoff. When spraying overhead in living areas, cover surfaces below the treated area with plastic sheeting or similar material. Do not contact with treated surfaces until spray deposits have dried. Retreat as needed to maintain protection.

Method

[Spray](#)

Rates

[field_rates 0](#)

•

Timings

[N. A.](#)