

# **WOOD-INFESTING PESTS - DRYWOOD TERMITE AND WOOD INFESTING BEETLES**

## General Information

### PRODUCT FACTS

- Two modes of action
- Contact activity & systemic action
- Quick knockdown & residual control
- Low odor
- Non-staining
- No phytotoxicity on a wide range of ornamentals

### Temprid SC Insecticide

- Temprid SC Insecticide is a suspension concentrate formulation of two insecticide active ingredients, imidacloprid and b-cyfluthrin. One gallon of the product contains 2 lbs of imidacloprid and 1 lb of bcyfluthrin.
- Shake well before using.

### Controls

- Indoor or General Household Pests
- Outdoor/Perimeter Pests
- Wood-Infesting Pests

### Where To Apply

Apply where pests have been seen or found, or can find shelter.

- In and around buildings and structures

- On established landscape ornamentals around residential and commercial properties

#### Dilution Rates

- When 0.27 fl oz (8 milliliters) is diluted in one gal of water, the combined active ingredient concentration (0.075%) contains 0.05% imidacloprid and 0.025% b-cyfluthrin.
- When 0.54 fl oz (16 milliliters) is diluted in one gal of water, the combined active ingredient concentration (0.15%) contains 0.10% imidacloprid and 0.05% b-cyfluthrin.

#### Mixing Information

- Mix the appropriate amount of Temprid SC Insecticide with water.
- Add product when filling spray tank with water; shake or agitate mixture.
- Diluted spray mixture can be stored overnight. Agitate before using.

#### How To Apply

- General surface (outdoors only), spot treatment, and void injections by mist, foam or crack & crevice sprays.
- Foliar application to established landscape ornamentals.

#### Re-Apply

- Every 7 to 10 days, if needed

#### Re-Entry

- Avoid contact with treated surfaces until dry.
- People and pets may re-enter after the treated area is dry.

#### Limitations, Restrictions, and Exceptions

#### WOOD-INFESTING INSECTS

### Where To Apply:

- For treatment of wood infested with, or subject to infestation by, wood-infesting pests.
- Apply where pests have been seen, found, or can find shelter.

### How To Apply:

- Apply spray or foam as described in application section.
- Treatment dilutions may also be applied to wood surfaces by paint brush or rollers.
- Do not contact treated surfaces until dry.

### When To Apply:

- Re-apply every 7 to 10 days if needed.

### Foam Applications:

- Mix end-use dilution with manufacturer's specified volume of foaming agent.

## DRYWOOD TERMITES & WOOD-INFESTING BEETLES

Galleries and structure voids: Treat by applying sprays, mists, or foams. Locate galleries by using visual signs (frass or pellets, blistered wood, emergence or clean out holes), the presence of live insects, mechanical sounding techniques, or listening devices (e.g., stethoscopes, acoustic emission detectors). Penetrate the gallery system by drilling holes to receive the injector tip or treatment tool. Distribute drill holes to adequately cover the gallery system. Apply as a low pressure spray (do not exceed 50 psi at nozzle tip) or by misting, or where appropriate, by foaming. It is not necessary to treat to the point where runoff is detected from adjacent holes.

- Avoid drilling where electrical wiring, plumbing lines, etc. are located.
- Do not apply where electrical shock hazards exist.
- Drill holes in commonly occupied areas must be sealed after treatment.

Wood surfaces: Treat by spray, mist, or where appropriate, foam applications. For

inaccessible surfaces, drill and treat the interior of structural voids. Surfaces treated may include exposed wooden surfaces in crawlspaces, basements, or attics, wooden exterior surfaces such as decks, fencing, or siding, structural voids, channels in damaged wood, in spaces between wooden members of a structure, and junctions between wood and foundations. Apply by brushing or as a coarse, low pressure spray (do not exceed 50 psi at nozzle tip) to the wood surface; apply sufficient volume to cover the surface to the point of wetness, but avoid applying to the point of runoff.

When spraying wood surfaces overhead in living areas, cover surfaces below the treated area with plastic sheeting or similar material. Do not contact treated surfaces until spray deposits have dried.

Method

[Spray](#)

[Foam Application](#)

Rates

[field rates 0](#)

[field rates 1](#)

[field rates 2](#)

•

Timings

[When pests are seen or found.](#)